

Kwikstage Loading Bay

Below are the photos of how to erect a loading bay using the following items:

1. 2 nos Kwikguard Special Panels for Up & Over Gate
2. 2 nos Loading Bay Transom – modern style
3. 10 nos 8ft Galvanised Steel Stage
4. 1 nos Up & Over Gate

You will also require other standard components ie ledgers, standards, braces etc.



